
<u>LINELOCK / ROLL CONTROL – PART #LL</u> <u>Designed for race applications</u>



Instructions:

Follow diagram above, Linelock uses 1/8 NPT fittings, different size adapters will be required for all other applications. Adapters not included.

<u>Electrical connections</u>: Either wire can be used, there is no polarity of the wires. One wire goes to ground, the other wire goes to switch. Use 5 amp fuse from the switch to 12 or 16 volt battery source.

We highly recommend that all installations be performed by a skilled mechanic

Designed for race applications.

NOT RECOMMENDED for use with ABS brake systems.

LL1515