

BRAKE PAD REPLACEMENT


MINTEX[®]
BRAKING WITH TRADITION

Important steps to change brake pads and disc

4 STEPS CLAP


- 1 **CLEAN THOROUGHLY!**
- 2 **LUBRICATE PROPERLY!**
- 3 **ACCESSORIES MUST BE REPLACED!**
- 4 **PLEASE ALLOW 200KM FOR BEDDING IN!**

1 Clean all mating parts on wheel hub and caliper with Mintex tools and brake cleaner. Check the disc run-out (max 0.07mm)!




2 Lubricate with Mintex Cera Tec!

Lubricate with Textar Hydra Tec!



Note: Do not use copper paste!

3 New accessories must be used when new pads are being fitted!



4 Very important step to further reduce squeal: Bedding at least 200km!

